

NEW



Khrome Werks Plug-And-Play Trailer Wiring Connector Kit with Isolator

- To be used with current Khrome Werks trailer hitches
- Plug-and-play wiring harness features an isolator module with a fused, separate circuit from battery positive to power the trailer lighting; works through built-in relays and prevent overloading of factory-lighting circuit
- 5-pin, die-cast, automotive style connector
- Mounts using mounting bracket that bolts directly to the safety chain bracket on current production Khrome Werks trailer hitches
- An isolator is a must for 2009 and later Harleys pulling trailers with conventional incandescent lighting (higher amperage requirements than trailers with LED lighting)

631564 Isolator Wiring Harness, FLT 96-12, FLSTC 96-12

631565 Isolator Wiring Harness, FLHX 10-13, FLTRX 10-13

NEW



motogadget

motogadget m-CAN

m-CAN connects all instruments of the motoscope series from motogadget directly to the OBD Interface of Harley Davidson models 04-13. Installation and connection of additional sensors or other equipment is no longer necessary. Models coming with HD-LAN are not compatible.

618059 For Twin Cam models

618060 For XL with DEUTSCH connectors

618061 For VRSC with DEUTSCH connectors

618062 For XL with MOLEX connectors



APPAREL



SEATS & TOURING



FOOT CONTROLS



HAND CONTROLS



LIGHTING



ELECTRICAL



EXHAUST



INTAKE



ENGINE



GASKETS



TRANNY & CLUTCH



DRIVELINE



WHEELS, TIRES & BRAKES



FRAMES



FORKS & SHOCKS



SHEETMETAL



INSTRUMENTS & GAUGES



LUBRICANTS & CHEMICALS



TOOLS & EQUIPMENT



LAST MINUTE