



## Montageanleitung

### Airless-Set für Yamaha XV1600

<b>Lieferumfang:</b>	1 Auszieh-Werkzeug	(A)
	2 Blindstopfen	(B)
	1 Verschluss-Schraube	(C)

#### Montage:

1. Bohren Sie mittig in die in die Zylindergehäuse eingesetzten Winkelstücke je ein 5mm-Loch und schneiden Sie je ein M6-Gewinde in die Löcher.
2. Setzen Sie das Auszieh-Werkzeug auf die Winkelstücke und entfernen Sie diese durch Anziehen der Schraube aus den Zylindergehäusen.
3. Demontieren Sie das komplette Sekundärluftsystem.



4. Schlagen Sie die Blindstopfen mit einem Kunststoffhammer vorsichtig in die Löcher der Zylindergehäuse ein.
5. Trennen Sie den Luftschlauch über den Vergaser ab (siehe Bild) und verschließen Sie das Ende mit der mitgelieferten Schraube und einer Originalschelle.

Das Thunderbike-Team wünscht viel Vergnügen.



Thunderbike  
Güterstrasse 5  
D-46499 Hamminkeln  
Telefon(0049)2852 - 6777 -33  
Telefax(0049)2852 - 5444  
info@thunderbike.de



## Installation Instructions

### Airless-Set for Yamaha XV1600

<b>Packing List:</b>	1 Removal tool	(A)
	2 Cylinder Plugs	(B)
	1 Screw	(C)

#### Installation:

Locate the original elbow found at the rear left corner of the rear cylinder head and front left corner of the front cylinder head. You must remove these elbows. To do so, you must drill a hole in the top of the elbow.

1. Place the included removal tool (A) over the elbow. Place a mark on the original elbow through the hole in the end of the removal tool. Remove the removal tool.
2. Drill a 5mm hole on the mark on the elbow. When hole is made, bore M6-thread in the hole.
3. Place Removal tool over the elbow. Insert included screw and tighten. As the screw is tightened, the original elbow will slowly but surely be drawn from the cylinder head. Continue until elbow is completely free from the cylinder head.
4. Repeat this on the second elbow.
5. Remove the complete secondary air system. Insert the new Cylinder plugs (B) with a rubber hammer in the holes in the cylinder head.



6. Locate air hose over the carburetor. Cut this hose at the point indicated by the arrow. Plug the hose with screw (C) and clasp with original clamp.

The secondary air system helps control emissions. Removal of this system may violate local emission regulations. Please check with your local motoring authority before installation.

Gute Fahrt!



Thunderbike  
Güterstrasse 5  
D-46499 Hamminkeln  
Telefon (0049) 2852 - 6777 - 33  
Telefax (0049) 2852 - 5444  
info@thunderbike.de