

**ACHSCOVER SCHWINGENACHSE  
FÜR HARLEY-DAVIDSON SPORTSTER S (2021-)**



## PACKLISTE:

Menge	Beschreibung
1	Achscover links (15mm)
1	Achscover rechts (20mm)
1	Gewindestange 342mm

## MONTAGEANLEITUNG:

Schrauben Sie die Gewindestange in das rechte Achscover.

Schieben Sie die Stange von der rechten Fahrzeugseite in die Bohrung der Schwingenachse und schrauben Sie die Stange nun so weit ein, dass der Achsenkopf ganz abgedeckt ist.

Schrauben Sie dann das linke Achscover auf die freie Seite der Gewindestange und ziehen Sie es fest.

Prüfen Sie nach der ersten Fahrt, ob die Cover noch immer fest angezogen sind!

Das Thunderbike-Team wünscht viel Vergnügen.  
Gute Fahrt!



Thunderbike  
Güterstrasse 5  
D-46499 Hamminkeln  
Telefon(0049)2852 - 6777 -33  
Telefax(0049)2852 - 5444  
info@thunderbike.de

**SWINGARM AXLE COVER SET**  
**FOR HARLEY-DAVIDSON SPORTSTER S (2021-)**



## PACKING LIST:

amount	item
1	Left axle cover (15mm)
1	Right axle cover (20mm)
1	Thread rod 342mm

## MOUNTING INSTRUCTIONS:

Screw the thread rod into the right axle cover.

Beginning on the right, push the thread rod through the swingarm axle and screw it until the cap covers the whole axle head.

Screw the left axle cap on the free end of the thread rod until it is tight.

Check if the covers are still tighten after the test ride!

The Thunderbike team wishes you fun with your new parts.  
Have a nice and safe ride!



Thunderbike  
Güterstrasse 5  
D-46499 Hamminkeln  
Telefon(0049)2852 - 6777 -33  
Telefax (0049) 2852 - 5444  
info@thunderbike.de