

**ACHSCOVER HINTERACHSE**  
**FÜR HARLEY-DAVIDSON SPORTSTER S (2021-)**



## PACKLISTE:

Menge	Beschreibung
1	Achscover links (25mm)
1	Achscover rechts (32,5mm)
1	Gewindestange 388mm

## MONTAGEANLEITUNG:

Schrauben Sie die Gewindestange in das linke Achscover.

Schieben Sie die Stange von der linken Fahrzeugseite in die Bohrung der Hinterradachse bis der Achsenkopf ganz abgedeckt ist.

Schrauben Sie dann das rechte Achscover auf die freie Seite der Gewindestange und ziehen Sie es fest.

Prüfen Sie nach der ersten Fahrt, ob die Cover noch immer fest angezogen sind!

Das Thunderbike-Team wünscht viel Vergnügen.  
Gute Fahrt!



Thunderbike  
Güterstrasse 5  
D-46499 Hamminkeln  
Telefon(0049)2852 - 6777 -33  
Telefax(0049)2852 - 5444  
info@thunderbike.de

**REAR AXLE COVER SET**  
**FOR HARLEY-DAVIDSON SPORTSTER S (2021-)**



## PACKING LIST:

amount	item
1	Left axle cover (25mm)
1	Right axle cover (32,5mm)
1	Thread rod 388mm

## MOUNTING INSTRUCTIONS:

Screw the thread rod into the left axle cover.

Beginning on the left, push the thread rod through the rear axle until the cap covers the whole axle head.

Screw the right axle cap by hand on the free end of the thread rod until it is tight.

Check if the covers are still tighten after the test ride!

The Thunderbike team wishes you fun with your new parts.  
Have a nice and safe ride!



Thunderbike  
Güterstrasse 5  
D-46499 Hamminkeln  
Telefon (0049) 2852 - 6777 -33  
Telefax (0049) 2852 - 5444  
info@thunderbike.de