

**GRIFF-SET "BASE RUBBER"**  
**FÜR HARLEY-DAVISON TOURING (2008-)**  
**FÜR HARLEY-DAVIDSON SOFTAIL (2016-)**



## MONTAGEANLEITUNG:

Öffnen Sie das Gasgriffgehäuse und ziehen Sie den Originalgriff vom Lenker ab.

Fetten Sie das Lenkerende, auf dem der Gasgriff sitzt, leicht ein.

Schieben Sie die mitgelieferte Anlaufscheibe soweit es geht auf das Lenkerende.

Schieben Sie den neuen Griff auf den Lenker und schließen Sie das Gasgriffgehäuse um den Griff. Achten Sie darauf, dass dabei die Anlaufscheibe (Pfeil) im Gehäuse sitzt.



Schrauben Sie das Gasgriffgehäuse wieder zu.

Entfernen Sie den Ring (1) an der Außenseite des Griffes und fixieren Sie den Griff mit den Schrauben (2) an der Verzahnung. Stecken Sie den Ring (1) wieder auf und schrauben Sie ihn an.



**Entfernen Sie den originalen Kupplungsgriff vom Lenker.**

**Schieben Sie den neuen Kupplungsgriff auf den Lenker und entfernen Sie den Ring an der Außenseite des Griffes.**

**Klemmen Sie den Griff durch Anziehen der vier Gewindestifte am inneren und äußeren Ende an den Lenker.**

**Schrauben Sie den Ring mit drei Gewindestiften an die Außenseite des Griffes.**

**Montieren Sie zuletzt die Toppers an die Griffenden.**

**Das Thunderbike-Team wünscht viel Vergnügen.  
Gute Fahrt!**



Thunderbike  
Güterstrasse 5  
D-46499 Hamminkeln  
Telefon (0049) 2852 - 6777 - 33  
Telefax (0049) 2852 - 5444  
info@thunderbike.de

**GRIP SET “BASE RUBBER”  
FOR HARLEY-DAVISON TOURING (2008-)  
FOR HARLEY-DAVIDSON SOFTAIL (2016-)**



## INSTALLATION INSTRUCTIONS:

Open the throttle clamp and pull away the grip from the handlebar.

Grease the handle bar end a bit. Push the plastic grommet onto the right handlebar end.

Push the new grip to the handlebar and close the throttle clamp, make sure the pad (see arrow in the picture) is inside the clamp.



Screw together both parts of the clamp.

Remove the ring (1) on outer side of the grip and install the grip with the two small screws (2) to the gearing.

Mount again the ring (1) to the grip.



**Remove the grip from left side of the handlebar.**

**Push the new grip to the handlebar and remove the outside ring.**

**Mount the grip with its four screws to the handlebar. Mount again the ring to the grip.**

**At least install the toppers on the outside rings of both grips.**

**Have a nice ride!**



Thunderbike  
Güterstrasse 5  
D-46499 Hamminkeln  
Telefon (0049) 2852 - 6777 - 33  
Telefax (0049) 2852 - 5444  
info@thunderbike.de