

STOßDÄMPFERANSCHLÄGE
FÜR HARLEY-DAVIDSON DYNA & SPORTSTER



PACKLISTE:

Menge	Beschreibung
2	Stoßdämpferanschlag

MONTAGEANLEITUNG:

Schrauben Sie die Dämpferanschlüge auseinander und montieren Sie diese anschließend auf den Kolbenstangen der Stoßdämpfer (siehe Pfeil).



Überprüfen Sie die Schraubverbindungen nach einer Probefahrt.

Achtung: Das Fahrverhalten ändert sich, da der Federweg begrenzt wird!

Das Thunderbike-Team wünscht viel Vergnügen.
Gute Fahrt!



Thunderbike
Güterstrasse 5
D-46499 Hamminkeln
Telefon (0049) 2852 - 6777 - 33
Telefax (0049) 2852 - 5444
info@thunderbike.de

SHOCK BUMPER

FOR HARLEY-DAVIDSON DYNA & SPORTSTER



PACKING LIST:

amount	item
2	Shock bumper

MOUNTING INSTRUCTIONS:

Mount the shock bumpers to the piston rod of each shock absorber (see picture).



Check the correct fitting after a test ride.

Attention: The bike handling will be changed!

The Thunderbike team wishes you fun with your new parts.
Have a nice and safe ride!



Thunderbike
Güterstrasse 5
D-46499 Hamminkeln
Telefon (0049) 2852 - 6777 - 33
Telefax (0049) 2852 - 5444
info@thunderbike.de