

FRONTFENDER „RECALL“

**FÜR HARLEY-DAVIDSON
CVO PRO STREET BREAKOUT (2016-2017)**



PACKLISTE:

Menge	Beschreibung
1	Frontfender
4	Inbusschraube M8*30
4	U-Scheibe Ø8
4	Poly-Stopmutter M8

MONTAGEANLEITUNG:

Entfernen Sie den originalen Frontfender.

Montieren Sie den TB-Frontfender mit den beiliegenden Schrauben, Scheiben und Muttern an der Originalposition.
Ziehen Sie die Schrauben mit 20-24 Nm (14,8-17,7 ft-lbs) fest.

Kontrollieren Sie die Schraubverbindungen nach einer Probefahrt.

Das Thunderbike-Team wünscht viel Vergnügen.
Gute Fahrt!



Thunderbike
Güterstrasse 5
D-46499 Hamminkeln
Telefon(0049)2852 - 6777 -33
Telefax (0049)2852 - 5444
info@thunderbike.de

FRONT FENDER „RECALL“

**FOR HARLEY-DAVIDSON
CVO PRO STREET BREAKOUT (2016-2017)**



PACKING LIST:

amount	item
1	Front fender
4	Allen head screw M8*30
4	Washer Ø8
4	Nut M8

MOUNTING INSTRUCTIONS:

Remove the OEM front fender.

Mount the new TB front fender on the OEM position using the included screws, washer and nuts.

Tighten the screws with 20-24 Nm (14,8-17,7 ft-lbs) torque.

Check all bolted connections after a test ride.

The Thunderbike team wishes you fun with your new parts.
Have a nice and safe ride!



Thunderbike
Güterstrasse 5
D-46499 Hamminkeln
Telefon (0049) 2852 - 6777 - 33
Telefax (0049) 2852 - 5444
info@thunderbike.de