

FRONTFENDER
FÜR HARLEY-DAVIDSON FAT BOB (2018-)



PACKLISTE:

Menge	Beschreibung
1	Frontfender
1	Fenderhalter Links
1	Fenderhalter Rechts
4	Inbusschraube M6
4	Unterlegscheibe M6
4	Mutter M6

MONTAGEANLEITUNG:

Demontieren sie den Frontfender samt dem originalen Fenderhalter von der Gabel.

Befestigen Sie die neuen TB-Fenderhalter mit den mitgelieferten Schrauben, U-Scheiben und Muttern an dem neuen Frontfender (siehe Bild).



Schrauben Sie die Halter nun mit den Originalschrauben, wie abgebildet, an die Gabel.

Das Thunderbike-Team wünscht viel Vergnügen.
Gute Fahrt!



Thunderbike
Güterstrasse 5
D-46499 Hamminkeln
Telefon (0049) 2852 - 6777 - 33
Telefax (0049) 2852 - 5444
info@thunderbike.de

FRONT FENDER
FOR HARLEY-DAVIDSON FAT BOB (2018-)



PACKING LIST:

amount	item
1	Front fender
1	Bracket left
1	Bracket right
4	Lens head screw M6
4	Washer M6
4	Locknut M6

MOUNTING INSTRUCTIONS:

Remove the front fender and the original fender bracket from your front fork.

Mount the new TB fender brackets to your new front fender using the included lens head screws, washers and locknuts (see picture).



Now mount the brackets to your front fork like on the picture, using the OEM bolts.

Have a nice ride!



Thunderbike
Güterstrasse 5
D-46499 Hamminkeln
Telefon (0049) 2852 - 6777 - 33
Telefax (0049) 2852 - 5444
info@thunderbike.de