

FRONTFENDER

FÜR HARLEY-DAVIDSON SPORTSTER S (2021-)
MIT 21“-VORDERRAD



PACKLISTE:

Menge	Beschreibung
1	Frontfender
1	Fenderhalter Links
1	Fenderhalter Rechts
4	Hülse $\varnothing 6 \times \varnothing 15 \times 10 \text{mm}$
2	Linsenschraube M6*40
2	Linsenschraube M6*50
2	Spacer
2	Linsenflanschschraube M6*20
6	Unterlegscheibe M6
6	Poly-Stop-Mutter M6

MONTAGEANLEITUNG:

Demontieren sie den Frontfender samt dem originalen Fenderhalter von der Gabel.

Hinweis: Montieren Sie den Frontfender vorerst probeweise mit 10mm Luft zum Reifen, um die Passgenauigkeit zu überprüfen! Erst dann sollte der Frontfender lackiert werden!

Befestigen Sie die neuen TB-Fenderhalter zuerst an der unteren Position an den Gabelfüßen. Platzieren Sie dabei die beiliegenden Hülsen zwischen Gabelfuß und Fenderhalter und verwenden Sie die beiliegenden Linsenschrauben M6*40.

Montieren Sie den Frontfender am Halter. Verwenden Sie dabei die beiliegenden Schrauben M6*50 mit den zugehörigen Hülsen an der oberen Position am Gabelfuß.

Platzieren Sie außerdem die Spacer zwischen Frontfender und Halter (Pfeil).



Mit den Schrauben M6*20 befestigen Sie den Fender zusätzlich am Halter.

Das Thunderbike-Team wünscht viel Vergnügen.
Gute Fahrt!



THUNDERBIKE

Güterstraße 5
46499 Hamminkeln
Germany

Phone: +49 2852 6777 80
Mail: info@thunderbike.de

FRONT FENDER

FOR HARLEY-DAVIDSON SPORTSTER S (2021-)
WITH 21" FRONT WHEEL



PACKING LIST:

amount	item
1	Front fender
1	Bracket left
1	Bracket right
4	Spacer $\varnothing 6 \times \varnothing 15 \times 10$ mm
2	Lens head screw M6*40
2	Lens head screw M6*50
2	Spacer
2	Lens flange screw M6*20
6	Washer M6
6	Locknut M6

MOUNTING INSTRUCTIONS:

Remove the front fender and the original fender bracket from your front fork.

Tip: First mount the raw fender to check clearance between fender and tire (10mm). Then the fender can be painted!

Mount the new TB fender brackets to the lower mounting position on your fork. Place the included spacers between fork and fender bracket and use the included lens head screw M6*40.

Install the fender to its brackets using the included screws M6*50 and spacers on the upper mounting position on your fork. Additionally place the included spacers between fender and its bracket (as shown).



Using the screws M6*20 to install the fender to the brackets too.

The Thunderbike team wishes you fun with your new parts.
Have a nice and safe ride!



THUNDERBIKE

Güterstraße 5
46499 Hamminkeln
Germany

Phone: +49 2852 6777 80
Mail: info@thunderbike.de