

RAHMENCOVER

FÜR HARLEY-DAVIDSON SOFTAIL (2018-)
AUSSER FATBOY & BREAKOUT



PACKLISTE:

Menge	Beschreibung
2	Rahmencover
2	Gewindestift M4*8

MONTAGEANLEITUNG:

Achtung: Dieses Kit passt nur in Verbindung mit einem Heckumbau (mitschwingender Heckfender), sowie einem Solositz-Montage-Kit (z.B. #11-74-320).

Demontieren Sie die Fenderstruts.



Montieren Sie die Rahmencover (A) mit den Originalschrauben am Rahmen.

Hinweis: Wenn Sie die hinteren Blinker an den Rahmencovern (A) montieren möchten, klemmen Sie die Blinker mit den beiliegenden Gewindestiften (B) von hinten fest.



Das Thunderbike-Team wünscht viel Vergnügen.
Gute Fahrt!



Thunderbike
Güterstrasse 5
D-46499 Hamminkeln
Telefon(0049)2852 - 6777 -33
Telefax (0049)2852 - 5444
info@thunderbike.de

FRAME COVER

FOR HARLEY-DAVIDSON SOFTAIL (2018-)
EXCL. FATBOY & BREAKOUT



PACKING LIST:

amount	item
2	Frame cover
2	Headless screw M4*8

MOUNTING INSTRUCTIONS:

Attention: This kit only fits in combination with a rear fender conversion (rigid rear fender) and a solo seat mounting kit (e.g. #11-74-320).

Remove the fender struts.



Mount the new frame cover (A) using the OEM screws.

Tip: If you want to mount the rear turn signals to the frame covers, use the included headless screws (B) to clamp the turn signals from behind.



The Thunderbike wishes you fun with your new parts.
Have a nice and safe ride!



Thunderbike
Güterstrasse 5
D-46499 Hamminkeln
Telefon(0049)2852 -6777 -33
Telefax (0049)2852 -5444
info@thunderbike.de