

**EINZELSITZ**  
**FÜR HARLEY-DAVIDSON MODELLE**



**PACKLISTE:**

<b>Menge</b>	<b>Beschreibung</b>
1	Einzelstz
1	Linsenschraube M6*16
1	Einziehmutter M6

## MONTAGEANLEITUNG:

Schieben Sie den vorderen Halter in das Rahmenoberrohr und drücken Sie den Sitz hinten herunter.

Markieren Sie das Loch für den hinteren Halter am Heckfender.

Bohren Sie an der Markierung ein 9,0mm-Loch in den Heckfender.

Montieren Sie die Einnietmutter in dieses Loch, um den hinteren Halter an zu schrauben.

**Tipp:** Falls Ihnen kein Werkzeug für die Einnietmuttermontage zur Verfügung steht, gehen Sie wie folgt vor:

Auf eine Schraube M6x30mm werden nacheinander eine Mutter, eine Unterlegscheibe und die Einnietmutter aufgeschraubt.

Die Einnietmutter wird dann in die Bohrung eingesetzt, die Schraube wird mit einem passenden Schlüssel festgehalten und die Mutter solange mit einem 10er Ring- oder Maulschlüssel angezogen, bis die Einnietmutter festsitzt.

Befestigen Sie das hintere Ende des Sitzes mit der Linsenkopfschraube an der eingienieteten Mutter.

Das Thunderbike-Team wünscht viel Vergnügen.  
Gute Fahrt!



Thunderbike  
Güterstrasse 5  
D-46499 Hamminkeln  
Telefon(0049)2852 - 6777 -33  
Telefax (0049)2852 - 5444  
info@thunderbike.de

**SOLO SEAT**  
**FOR HARLEY-DAVIDSON MODELS**



**PACKING LIST:**

<b>amount</b>	<b>item</b>
1	Solo seat
1	Lens head screw M6*16
1	Blind rivet nut M6

## MOUNTING INSTRUCTIONS:

Push the front bracket into the frame tube and press down the rear end of the seat.

Mark the position of the hole for rear bracket mounting on the rear fender.

Drill a Ø9.0mm hole at the marked position to the rear fender.

Mount a clinch nut into the drilled hole to tighten the rear bracket.

**Tip:** If you don't have the tools to mount the clinch nut, the following tip will help you:

Took a M6x30mm screw and mount a nut, a washer and the clinch nut in succession on it.

The clinch nut must be inserted into the drilled hole.

The screw must be hold on tight with a suitable wrench and the nut must be tightened with a 10er combination wrench till the nut is fixed.

Mount the rear seat bracket with the lens head screw to the fender.

The Thunderbike team wishes you fun with your new parts.  
Have a nice and safe ride!



Thunderbike  
Güterstrasse 5  
D-46499 Hamminkeln  
Telefon (0049) 2852 - 6777 - 33  
Telefax (0049) 2852 - 5444  
info@thunderbike.de