SEITLICHER KENNZEICHENHALTER MEDIUM

FÜR HARLEY-DAVIDSON SPORTSTER 883/1200 (2004-)

LIEFERUMFANG:

1	Seitlicher Kennzeichenhalter
2	Schrauben mit Scheiben und Hutmuttern
1	Stoßdämpferschraube mit Scheibe
1	Achshülse mit Scheibe und Schraube
2	Kabelbinder

MONTAGEANLEITUNG:

Bocken Sie das Fahrzeug so auf, dass das Hinterrad entlastet wird und sorgen Sie dafür, dass es sicher steht!

Entfernen Sie die untere Schraube des linken Stoßdämpfers.

Achten Sie darauf, dass die Mutter der Hinterradachse auf der rechten Seite ist (Achse gegebenenfalls drehen)!

Schieben Sie die Achshülse des Kennzeichenhalters über die Hinterachse.

Legen Sie die Wellscheibe und/oder die originale Unterlegscheibe zwischen Kennzeichenhalter und Stoßdämpferauge, so dass der Kennzeichenhalter plan an der Achshülse anliegt.

Achten Sie darauf, dass die Achshülse bündig an der Schwinge anliegt und befestigen Sie dann den Kennzeichenhalter an der Achshülse.

Bringen Sie den Stoßdämpfer mit der mitgelieferten Schraube und der Originalmutter wieder an.

Befestigen Sie die Kennzeichenplatte und das Kennzeichen am Kennzeichenhalter, achten Sie dabei auf ausreichenden Abstand zum Reifen und zum Heckteil!

Montieren Sie die Kennzeichenbeleuchtung und schließen Sie diese an das Bordnetz an.
Verlegen Sie das Kabel so, dass es nicht in Kontakt mit dem Hinterrad kommen kann und befestigen Sie es mit den Kabelbindern!

Überprüfen Sie alle Schrauben auf festen Sitz!

Das Thunderbike-Team wünscht viel Vergnügen.

Thunderbike
Güterstrasse 5
D-46499 Hamminkeln
Telefon(0049)2852 - 6777 -33
Telefax(0049)2852 - 5444
info@thunderbike.de

SIDE MOUNT LICENSE BRACKET MEDIUM

FOR HARLEY-DAVIDSON SPORTSTER 883/1200 (2004-)

THUNDERBIKE
Since 1985
CUSTOMS

PACKING LIST:

1	License bracket
2	Bolts with washers and nuts
1	Damper bolt with washers
1	Axle bushing with washer and bolt
2	Cable straps

INSTALLATION INSTRUCTIONS:

Lift up the motorcycle on the rear frame end till the rear wheel loose contact to the ground. Make sure the motorcycle is secure and there is no danger of it falling or rolling!

Remove the lower bolt of the left damper.

Make sure the nut of the rear axle is on the right side of the bike, otherwise turn around the axle!

Slide the axle bushing on the axle.

Position the waved washer and (if necessary) the OEM washer between the bracket and the damper mount. Make sure the bracket is flush mount to the swingarm and the axle bushing.

Mount again the damper with the new bolt and the OEM nut.

Confirm the license plate on the bracket with enough distance to wheel and fender!

Mount the license plate lightening and connect it to the wiring, make sure the cable doesn't get contact to the wheel! Fix the cable with the straps.

Double check all nuts and bolts! Making sure everything is safe and secure before and after test drive!

The Thunderbike team wished you both safety and fun
with your new parts.
Gute Fahrt!

Thunderbike
Güterstrasse 5
D-46499 Hamminkeln
Telefon(0049)2852 - 6777 -33
Telefax(0049)2852 - 5444
info@thunderbike.de